

CUSTOMER PLEASE NOTE

TO ASSEMBLE THE THICKER FIRE BOARDS IN THE FIRE BOX

- 1) FIT THE REAR FIRE BOARDS BY POSITIONING AT THE REAR FIREBOX. FIT THE CHANNEL RETAINER OVER THE TOP OF THE FIRE BOARDS AS ILLUSTRATED BELOW.
- 2) PLACE LEFT HAND FIRE BOARDS IN POSITION AND FIT CHANNEL RETAINER OVER THE TWO FIRE BOARDS.
- 3) LINE THE TWO METAL RETAINERS UP WITH THE TWO HOLES ON THE FRONT FIRE BOARDS, PUT THE SCREW THROUGH THE METAL RETAINER, PLACE THE TWO WASHERS AND THE SPACER ONTO THE SCREW.
- 4) FIT THE ASSEMBLY OF THESE PARTS TO THE FIRE BOARD. LIGHTLY TIGHTEN THE SCREW. **DO NOT OVERTIGHTEN.**
- 5) FIT RIGHT HAND FIRE BOARDS BY FOLLOWING THE STEPS IN 3 & 4 ABOVE.

BE SURE TO BURN THE WOODFIRE ON LOW HEAT FOR 8 HOURS IN ORDER TO CURE THE FIRE BOARDS.

