

Stainless Steel BBQ Trolley

Before assembly check contents of pack against the list below

<u>2 Shelf Model</u>	<u>1 Shelf Model</u>
1 x Base shelf	1 x Base shelf
2 x Side shelf assembly	1 x Side shelf assembly
2 x Type A. leg	2 x Type A. leg
2 x Type B. leg	2 x Type B. leg
4 x Casters	4 x Casters
8 x M4 x 16 screw	4 x M4 x 16 screw
8 x M4 x 8 spacers	4 x M4 x 8 spacers
8 x M4 x 12 washer	4 x M4 x 12 washer
12 x M6 x 10 washer	12 x M6 x 10 washer
12 x M6 x 65 bolt	12 x M6 x 65 bolt
12 x M6 Nylock nut	12 x M6 Nylock nut

For assembly you will need.

1 x No.2 pozidrive screwdriver
2 x M10 spanners }
1 x M14 spanner } or 2 adjustable spanners

- 1.** Place BBQ upside down on a clean flat surface (e.g. Empty BBQ carton or carpet.) And fix the legs to the BBQ frame, using 8 x M6 x 65 bolts and M6 nylock nuts ensuring you have one type A. and one type B. leg on each side with the threaded holes facing out to back and front and closest to the BBQ. **Do not tighten bolts at this stage.**
- 2.** Remove protective coating from the ends of the base shelf with the holes in, with the remaining 4 x M6 x 65 bolts, nylock nuts and M6 x 12 washers fir the shelf between the legs with the flat side facing up towards to the BBQ. Tighten all nuts and bolts so the BBQ, shelf and legs are rigid do not over tighten the bolts as this will only distort the legs.

- 3. Fit the four casters using appropriate spanner.**
- 4. Turn BBQ and trolley up the right way and hook to side shelf over the screws in the side of the legs. Using the M4 x 16 screw, spacer and washer in the same order as the top screws already fitted screw through the slot in the lower end of the slide shelf into the leg and tighten fully. Repeat item 4. For other side. You should now be able to lift the side shelf up and back and swing it down to make storage easier.**
- 5. Remove all remaining protective coating from shelves.**