




STOVES 1100E 1100MM WIDE STERLING ELECTRIC RANGE COOKER



COOKTOP



OVEN



- | | |
|---|---|
| 1 | - Plate Warmer control |
| 2 | - Thermostat 260-60 degrees |
| 3 | - Multi Function Oven selector |
| 4 | - Grill/Fan Grill switch (clockwise full grill, anti clockwise 1/2 grill) |
| 5 | - Clock Timer |
| 6 | - Fan forced Oven |
| 7 | - Small Front element |
| 8 | - Large Rear element |
| 9 | - Slow Cooker (on/off) |