



**STOVES 1100E 1100MM WIDE STERLING ELECTRIC RANGE COOKER**




**INDUCTION CONTROLS**



**OVEN**

- |   |   |
|---|---|
| 1 | - Plate Warmer control  |
| 2 | - Thermostat 260-60 degrees   |
| 3 | - Multi Function Oven   |
| 4 | - Grill/Fan Grill switch (clockwise full grill, anti clockwise 1/2 grill) |
| 5 | - Clock Timer   |
| 6 | - Fan forced Oven   |
| 7 | - Small Front element   |
| 8 | - Large Rear element  |
| 9 | - Slow Cooker (on/off)  |



**MULTI FUNCTION OVEN**

**GRILL**

**STORAGE DRAWER**

**SLOW COOKER**

STOVES 1100E 1100MM WIDE STERLING ELECTRIC RANGE COOKER

INDUCTION COOKTOP

