

ESSE COOKER ASSEMBLY

Item #	Document Number	Title	Material	Qty
1	ECSAC103	FIRE BOX ASSEMBLY		1
2	ECS00006	SIDE PANEL	Cold Roll 1.6mm	2
3	ECSAC304	DAMPER ASSEMBLY		1
4	ECSAC196	LEG ASSEMBLY		4
5	ECSAC154	ASH PAN ASSEMBLY		1
6	ECSAC036	AIRWASH ASSY		1
7	ECS00607	FLUE ACCESS COVER - 022	Cold Roll 1.6mm	1
8	ECS00606	FLUE HEAT SHIELD - 051	Hot Rolled 5.0mm	1
9	ECS00305	FLUE GAS RESTRICTOR	Cold Roll 1.6mm	1
10	ECS00176	BASE HEAT SHIELD	Cold Roll 1.6mm	1
11	ECS00158	PRIMARY SLIDER FRENCH	Hot Rolled 5.0mm	1
12	ECS00135	BOILER PLATE	Hot Rolled 5.0mm	1
13	ECS00111	PRIMARY AIR COVER, PREVIOUS FC-051	Cold Roll 1.6mm	1
14	ECS00083	PRIMARY SLIDE GUIDE	Stainless Steel, 304	1
15	ECSAC038	HEAT SHIELD ASSEMBLY		1
16	ECS00609	HOTPLATE INSULATION	Insulation x 10mm	1
17	ECSAC573	HINGE SHORT ASSEMBLY		4
18	ECSAC572	HINGE LONG ASSEMBLY		4
19	ECSAC554	RH SMALL DOOR ASSY		1
20	ECSAC551	OVEN DOOR ASSEMBLY		1
21	ECSAC552	FIRE DOOR		1
22	ECSAC553	LH SMALL DOOR ASSY		1
23	ECS00578	BRASS H NUT	Brass, yellow brass	2
24	ECS00558	TOP CASTING FRENCH	Cast Iron	1
25	ECS00550	HOT PLATE	Cast Iron	1
26	ECSAC596	WATER BOOSTER INDIRECT		1
27	ECS00633	SIDE BRICK BACK	Vermiculite	2
28	ECS00632	SIDE BRICK MIDDLE	Vermiculite	2
29	ECS00630	SIDE BRICK FRONT	Vermiculite	2
30	ECS00628	BACK BRICK	Vermiculite	1
31	ECS00743	GRATE FRENCH		2
32	ECSAC109	BAFFLE PLATE ASSEMBLY		1
33	ECS00556	TOP OVEN SHELF RUNNER, RIGHT HAND	Cast Iron	1
34	ECSAC563	FLUE BOX ASSEMBLY		1
35	ECS00555	COAL BAR	Cast Iron	1
36	ECS00557	TOP OVEN SHELF RUNNER, LEFT HAND	Cast Iron	1
37	ECS00565	TOWEL RAIL BRACKET RH	Cast Iron	1
38	ECS00566	TOWEL RAIL BRACKET LH	Cast Iron	1
39	ECS00597	ECS WIRE OVEN SHELF		2
40	ECSAC640	FLUE INSULATION ASSY		1
41	ECSAC634	TOP EXTERIOR SEAL		1
42	ECS00079	DOOR CATCH	FCMS	3
43	ECS00704	TOWEL RAIL	Stainless steel Polished Finish	1
44	ECS00599	FIRE GUARD		1
45	ECSAC568	BOLSTER ASSEMBLY		2

